

Specifications

Model	87491
Colour	Light Blue & Pink
Capacity	150 ml
Run Time	Up to 12 hours
Light Modes	Warm White/Colour rotating/Off
Coverage	Up to 400 sq. ft.
Adapter Power	5 V USB
Sound Options	Birds Chirping/River Water/Forest Sounds/Soft Wind
Projection Templates	Night Sky/Flowers/Clouds & Kites

Troubleshooting

SYMPTOM	CAUSE	SOLUTION
No mist	Unit is out of water	Add additional water.
No mist or little mist	Unit needs to be cleaned; oils are clinging to ceramic disc or sensor	Clean unit as advised in instructions with clean water and clean ceramic disc/sensor with brush or swab.
	Water level is higher than max level line	Clean unit and add water ½ way to fill line and additional water after getting mist. Remove excess water and restart the diffuser.
Blinking Lights	Water level indicator is dirty	Clean unit as advised, making sure to swab the sensor/disc inside the bottom of the unit.
Unit will not stop running even though empty	Unit is out of water	Clean unit as advised, making sure to swab the sensor/disc inside the bottom of the unit.
No misting and unit is spraying water	Water level indicator is dirty	Change to warmer water.

CAUTION: Keep away from children and pets.

nowfoods.ca/essential-oils

This diffuser has a 1-year manufacturer guarantee

Customer Service: 888-548-0040

DO NOT RETURN TO RETAILER

Manufactured for NOW Foods, 60108 USA
 Imported & Distributed by/Importé et distribué par:
 Puresource, Guelph, ON N1H 6J3 Canada nowfoods.ca

Code 87491

V 2023-03-30



Essential Oil Info

NOW® Essential Oils are genuine reflections of the botanicals from which they're derived. When properly diffused, these botanical extracts can encourage wellness, tranquility and even inspiration. Our essential oils are highly concentrated and identity verified to ensure quality. We take and we use only fresh botanicals bursting with vitality and beneficial compounds. Strict attention to detail, meticulous extraction methods, and a focus on safety and purity are what set NOW® Essential Oils apart from other essential oils. We take the necessary steps to ensure our oils are brought to you in a manner that's scientifically and environmentally responsible.



For more information visit nowfoods.ca/essential-oils.



Unicorn USB Diffuser

INSTRUCTIONS & CARE



nowfoods.ca/essential-oils



Essential Oil Recipes

Add the following oils to a diffuser and enjoy:

Balancing Blends

Daily Balance

- 2 drops of NOW® Geranium Oil
- 2 drops of NOW® Rose Absolute Oil
- 2 drops of NOW® Clary Sage Oil

Mind Ease

- 3 drops of NOW® Lavender Oil
- 3 drops of NOW® Peppermint Oil
- 3 drops of NOW® Chamomile Oil

Purifying Blends

Purifying Room

- 1 drop of NOW® Tea Tree Oil
- 1 drop of NOW® Grapefruit Oil
- 8 drops of NOW® Lemon Oil

Spring Cleaning

- 6 drops of NOW® Lemongrass Oil
- 3 drops of NOW® Lemon Oil
- 1 drop of NOW® Eucalyptus Oil

Uplifting Blends

Orange You Delightful

- 2 drops of NOW® Orange Oil
- 5 drops of NOW® Vanilla Concentrate Oil

Energizing

- 1 drop of NOW® Peppermint Oil
- 1 drop of NOW® Rosemary Oil
- 2 drops of NOW® Cinnamon Oil

Relaxing Blends

Peace of Mind

- 5 drops of NOW® Lavender Oil
- 3 drops of NOW® Chamomile Oil

Calming Night

- 3 drops of NOW® Cypress Oil
- 3 drops of NOW® Lavender Oil
- 3 drops of NOW® Marjoram Oil

Romance Blends

Love is in the Air

- 1 drop of NOW® Patchouli Oil
- 3 drops of NOW® Jasmine Absolute Oil
- 5 drops of NOW® Geranium Oil

Things are Just Rosey


- 1 drop of NOW® Geranium Oil
- 10 drops of NOW® Rose Absolute Oil

Congratulations on your purchase of NOW® Solutions Unicorn USB Diffuser designed for indoor use only. Please read the instructions carefully before using.


How it works

NOW® Solutions Unicorn USB Diffuser is made of recycled plastic and uses high frequency ultrasonic technology that vibrates water inside the unit into an ultra-fine mist which helps to maintain essential oil integrity and holistic properties. When your favourite essential oils are added, they are immediately dispersed into the air, providing immediate healthful benefits while helping to ionize the air. The addition of the projection templates (night sky, flowers, clouds & kites) coupled with music sounds (birds chirping, river water, forest sounds & soft winds) (see image below) creates a relaxing, healthful environment for any child.


What's included



How to use



How to operate



NOTE: Oil mist can damage wooden and painted surfaces; wipe up any residue quickly and often.


IDEAL PROJECTION DISTANCE FROM THE DIFFUSER TO THE CEILING IS BETWEEN 6' TO 7'

How to clean

We recommend that you clean your NOW® Solutions Unicorn USB Diffuser every time you change oils. Oils are corrosive, and over time, they build up on the ceramic parts. To ensure a long life for your diffuser, follow these simple cleaning and maintenance instructions:

- Rinse with warm water and wipe clean as follows:
 - Remove the energy ring
 - Wipe with soft damp cloth to clean.
 - Wipe with cotton swab and rubbing alcohol when needed to break up excessive oil residue
 - Replace the energy ring after cleaning.
- We recommend cleaning the unit every time you change oils
- Do not use detergents or abrasive agents to clean the diffuser unit.

Maintenance



If defective in any way, do not return this diffuser to the retailer. Please contact the manufacturer's customer service for assistance.

Please read the instructions carefully before using. Manufacturer accepts no liability for damage caused by incorrect use of the NOW® Solutions Unicorn USB Diffuser.



⚠	1. Shut off and unplug the power before cleaning
⚠	2. Clean the unit by rinsing the water tank and wiping it dry with a clean cloth
⊘	3. Do not use detergents or abrasive agents to clean the diffuser unit
⚠	4. Clean unit when changing to a different oil
⚠	5. Use the original adapter provided by the manufacturer
⚠	6. If you don't use the device for a long time, unplug and pour water out
⊘	7. Never use steamed water or very cold water
⊘	8. Never touch water level sensor to avoid product hitting other objects
⊘	9. Never put your hand above the ceramic disc when product is working, as this could cause pain and damage to the machine
⚠	10. Never wrap the adapter with a cloth or paper, etc. Otherwise, it cannot dissipate heat normally and may cause deformation and burn the membrane from a short circuit. Never touch the adapter with wet hands
⊘	11. Do not use other liquids except for water & drops of essential oil
⊘	12. Do not aim the device at walls, ceilings, furniture surfaces as excess moisture could cause water damage
⚠	13. Do not take this unit apart exposing electrical parts
⚠	14. Never place on loose fabric that can block air flow and prevent the unit from misting and ventilating properly

For more recipe ideas visit nowfoods.ca/essential-oils